
World Class Design | World Class Function | 30 Years Expertise in Industrial Motor Control

DC THYRISTOR DRIVE 400 / 800 / 1200



Product Manual

HG105270EN00 Issue 1 (08/2021)

Please read this information before installing or using the product.

Install, use and maintain this product following the procedures provided.

The manual(s) cannot provide all details, variations and contingencies required for your installation, operation and maintenance of this product or the apparatus with this product installed. For further help or information, refer to your local Supplier sales office.

Application area

The equipment described is intended for industrial (non-consumer) motor speed control.

Intended users

To safely enable the user to obtain maximum benefit from the equipment:

- Ensure this information is available to all persons required to install, configure or service the described equipment or any other associated operation.
- Always store the manual in a conveniently accessible area for quick reference.
- Make it available for the next user/owner of the product.

This product is of the restricted sales distribution class according to IEC 61800-3 and has a "professional equipment" designation as defined in EN 61000-3-2.

Safety

Ensure all users and operators understand the included WARNINGS, CAUTIONS and NOTES, which alert the user to safety issues. COMPLY WITH WARNINGS AND CAUTIONS AT ALL TIMES. Each of these carries a special meaning and should be read carefully:



WARNING!

A WARNING is given when non-compliance with the warning may result in personal injury and/or equipment damage.



CAUTION!

A CAUTION is given when non-compliance with the caution may result in permanent equipment damage.

NOTE A note provides specific information to make important instructions clear.

Symbols

| Attention | Electrostatic Discharge (ESD) | Electric Shock Hazard |
|---|---|---|
| See the instructions for use. Specific warnings not found on the label. | This equipment contains ESD sensitive parts. Observe static control precautions when handling, installing and servicing this product. | Disconnect the mains supply before working on the unit. Do not touch presets, switches and jumpers! Always use the correct insulated adjustment tools. |



WARNING!

Only qualified personnel must install, operate and maintain this equipment. A qualified person is someone technically competent and familiar with all safety information, established safety practices, installation, operation, maintenance and the hazards involved with this equipment and any associated machinery.

Hazards

This equipment can endanger life through rotating machinery and high voltages.



WARNING! PERSONAL INJURY AND/OR ELECTRICAL SHOCK HAZARD

• Always isolate all power supplies from the equipment before starting any work.

- Never perform high voltage resistance checks on the wiring without first disconnecting the product from the circuit under test.
- Use guarding and additional safety systems to prevent injury and electric shock.
- Metal parts may reach 90°C during operation.



CAUTION! EQUIPMENT DAMAGE HAZARD

- We thoroughly test our products. However, before installation and start-up, inspect all equipment for transit damage, loose parts, packing materials, etc.
- Installation must observe the required environmental conditions for safe and reliable operation.
- In a domestic environment, this product may cause radio interference, requiring adequate measures to be taken. Obtain the permission of the supply authority before connecting to the low voltage supply.

General risks

Installation

- Ensure mechanically secure fixings are in use as recommended.
- Ensure cooling airflow around the product is as recommended.
- Ensure cables/wire terminations are as recommended and are torqued correctly.
- Ensure the product rating is correct do not exceed the rating.

Application risk

Electromechanical safety is the responsibility of the user. The integration of this product into other apparatus or systems is not the manufacturer's or distributor of the product's responsibility. It is the user's responsibility to ensure the compliance of the installation with any regulations in force.

Health and safety at work

Electrical devices can constitute a safety hazard. Thorough personnel training is an aid to SAFETY and productivity. SAFETY awareness not only reduces the risk of accidents and injuries in your plant but also has a direct impact on improving product quality and costs. If you have any doubts about the SAFETY of your system or process, consult an expert immediately. Do not proceed without doing so. If in doubt, refer to the Supplier.

Weight

Consideration should be given to the weight of our heavier products when handling.

Risk assessment

Under fault conditions or conditions not intended: the motor speed may be incorrect; the motor speed may be excessive; the direction of rotation may be incorrect; the motor may be energised.

In all situations, the user should provide sufficient guarding and/or additional redundant monitoring and safety systems to prevent risk of injury.

NOTE: During a power loss event, the product will commence a sequenced shut-down procedure. Therefore, the system designer must provide suitable protection for this case.

Maintenance

Only qualified personnel should maintain and effect repair using only the recommended spares, alternatively return the equipment to the factory for repair. The use of unapproved parts may create a hazard and risk of injury.



WARNING!

PERSONAL INJURY AND/OR EQUIPMENT DAMAGE HAZARD

When replacing a product, all user-defined parameters that define the product's operation must be installed correctly before returning to use. Failure to do so may create a hazard and risk of injury.

The packaging is inflammable and incorrect disposal may lead to the generation of lethal toxic fumes.

Repairs

Repair reports can only be given if the user makes sufficient and accurate defect reporting. Remember that the product without the required precautions can represent an electrical hazard and risk of injury, and that rotating machinery is a mechanical hazard.

Protective insulation

Non-isolated product



WARNING!

The motor must be connected to an appropriate safety earth. Failure to do so presents an electrical shock hazard. Exposed metal work in this equipment is protected by basic insulation and bonding to a safety earth.

This product is classified as a component and must be used in a suitable enclosure.

- 1. There is no isolation between the Power and Control Circuits. ALL connections to the Drive are HAZARDOUS. Mount the drive in an earthed enclosure.
- The Installer MUST provide Protection for the End User by using Double or Re-inforced Insulation. The drive's Control signal terminals operate at the output voltage of the drive. Therefore, User controls MUST be made safe by the use of suitably insulated components, i.e. Potentiometer, Run Switch.
- 3. **DO NOT** connect these Control signal terminals to low voltage equipment or any non-isolated potential as this will cause significant damage to both the Drive and attached equipment.

Contents

| 1 | Introduction | | | | |
|----|---|-------------------------|--|--|--|
| 2 | Mechanical dimensions | | | | |
| 3 | Guide for systems used in the EU | 3 | | | |
| 4 | Multiple drives | 3 | | | |
| 5 | Requirements for EMC compliance | 4 | | | |
| 6 | Installation 6.1 Motor installation 6.2 Drive Installation | 5 5 5 | | | |
| 7 | Typical applications | 6 | | | |
| 8 | Terminal descriptions | 7 | | | |
| 9 | Block diagram | 8 | | | |
| 10 | Commissioning 10.1 Initial settings - without power 10.2 Pre-operation motor checklist 10.3 Operating the drive 10.4 DC Tachogenerator Feedback | 9 9 9 11 12 | | | |
| 11 | l Options | 12 | | | |
| 12 | 2 Trouble shooting | 13 | | | |
| 13 | 3 Specifications | 15 | | | |

Disposal

This product contains materials that are consignable waste under the Hazardous Waste Regulations 2005. Metal and plastic materials can be recycled, however, disposal of the printed circuit board requires compliance with all valid environmental control laws.



Products that must be recycled in accordance with the WEEE Regulations are marked with the symbol opposite. Contact us when recyling the product.

1 Introduction

APPLICATION AREA: Industrial (non-consumer) "Motor speed control utilising DC Motors".

| DRIVE MODEL | AC SUPPLY VOLTAGE (V) | NOMINAL OUTPUT VOLTAGE (V) | MAXIMUM CURRENT (A) | NOMINAL POWER OUTPUT | DISSIPATION AT RATED CURRENT (W) | ISOLATION |
|----------------|--------------------------|----------------------------------|---------------------------|----------------------------|--|--------------|
| 400/LV60 | 60/30 | 48/24 | 4 | 200 W | 12 | non-isolated |
| 400 | 240/110 | 180/190 | 4 | 0.55 kW | 12 | non-isolated |
| 800/LV60 | 60/30 | 48/24 | 8 | 400 W | 24 | non-isolated |
| 800 | 240/110 | 180/90 | 8 | 1.2 kW | 24 | non-isolated |
| 1200/LV60 | 60/30 | 48/24 | 12 | 600 W | 36 | non-isolated |
| 1200 | 240/110 | 180/90 | 12 | 2.0 kW | 36 | non-isolated |

• All models are of open chassis construction. Enclosed versions are available as follows: 400E, 400ER, 800E, 800ER, 1200ER, 1200ER. E = enclosed; R = reversing.

- Closed-loop control of both armature current and feedback voltage for precise control of motor torque and speed.
- Motor and drive are protected by a stall timer that automatically removes power after 30 seconds if the required speed is not achievable.
- Provides for up to 150% of the preset maximum current for up to 30 seconds allowing for high, short-term torques, for example, during acceleration.
- Independent control of either the current or speed loops by external inputs allows for torque or speed control applications with overspeed or overcurrent protection.
- Derive the demand signal from a potentiometer, 0-10 V signal or 4-20 mA loop.
- Speed feedback signal selection: ARMATURE VOLTAGE, or shaft-mounted TACHOMETER.


| Input and | +aux input | speed output | rail outputs |
|-------------|----------------------|-----------------------------|---------------------------|
| outputs | -aux input | current output | +12 V regulated output |
| | current input | ramp output | +10 V precision reference |
| | 4-20 mA input | stall relay driver | -12 V regulated output |
| | 0 to 10 V input | zero speed driver | -24 V unregulated output |
| Adjustable | Max speed | Up ramp | Max current |
| parameters | Min speed | Down ramp | IR comp |
| | | | Stability |
| Switched | Max feedback | Tacho feedback | |
| functions | Torque control | AV feedback | |
| Jumper | Dual supply voltage | Phase angle limit | |
| functions | 4-20 mA input | 50% stall threshold | |
| Performance | Dual loop control | Precision tacho rectifier | Compact design |
| features | Relay driver outputs | International compatibility | Integral fusing |

2 Mechanical dimensions



WARNING! PERSONAL INJURY AND/OR EQUIPMENT DAMAGE HAZARD

The drives are NON-ISOLATED. **Do not** allow contact of the enclosure with the drive card electronics.



screw provided.

Figure 1 Mechanical dimensions

3 Guide for systems used in the EU

Special consideration must be given to installations in member states of the European Union regarding noise suppression and immunity. According to IEC 1800-3 (EN61800-3) the drive units are classified as complex components only for professional assemblers, with no CE marking for EMC.

The drive manufacturer is responsible for the provision of installation guidelines. The resulting EMC behaviour is the responsibility of the manufacturer of the system or installation. The units are subject to the LOW VOLTAGE DIRECTIVE 73/23/EEC and are CE marked accordingly.

Following the procedures outlined below will normally be required for the drive system to comply with the European regulations, some systems may require different measures. Installers must have a level of technical competence to correctly install. Although the drive unit itself is not subject to the EMC directive, considerable development work has been undertaken to ensure that the noise emissions and immunity are optimised.


★ EN618003 specifies two alternative operating environments. These are the Domestic (1st environment) and Industrial (2nd environment). There are no limits specified for conducted or radiated emissions in the industrial environment, hence it is usual for the AC supply filter to be omitted in Industrial systems.

Definition of an industrial environment: all establishments, other than those directly connected to a low-voltage power supply network that supplies buildings used for domestic purposes.

4 Multiple drives

The arrangement shown below is for multiple drives with one filter, showing the star point earthing method.

The filter should be rated for the worst case total armature current load. The drive units are designed to function normally on unfiltered AC supplies shared with other thyristor DC drives. (Not AC drives).





5 Requirements for EMC compliance

- Keep parallel runs of power and control cables at least 0.3 metres apart. Cross-overs must be at right angles.
- Keep sensitive components at least 0.3 metres from the drive and power supply cables.
- The AC connections from the filter to the drive must be less than 0.3 metres or, if longer, correctly screened.
- Do not run filtered and unfiltered AC supply cables together.
- Control signals must be filtered or suppressed, e.g. control relay coils and current carrying contacts. The drive module has built-in filters on signal outputs.
- The AC supply filter must have a good earth connection to the enclosure back plane. Take care with painted metal to ensure good conductivity.
- The AC input filter has earth leakage currents. Earth RCD devices may need to be set at 5% of rated current.
- The metal enclosure will be RF ground. The AC filter, drive earth and motor cable screen should connect directly to the metal cabinet for best performance.
- Linear control signal cables must be screened, with the screen earthed at the drive end only. Minimise the length of screen stripped back and connect it to an analogue earth point.
- (1) The motor cable must be screened or armoured with 360 degree screen terminations to earth at each end. The cable must have an internal earth cable and the screen must extend into the enclosure and motor terminal box to form a Faraday cage without gaps.
- (2) The internal earth cable must be earthed at each end. The incoming earth must be effective at RF.
 WARNING! The earth safety must always take precedence.




ELECTRIC SHOCK HAZARD

AC supply filters must not be used on supplies that are unbalanced or float with respect to earth.

The drive and AC filter must only be used with a permanent earth connection. No plugs/sockets are allowed in the AC supply.

The AC supply filter contains high voltage capacitors and should not be touched for a period of at least 20 seconds after the removal of the AC supply.





6 Installation



WARNING!

ELECTRIC SHOCK HAZARD

Disconnect the mains supply before working on the unit. DO NOT TOUCH PRESETS, SWITCHES AND JUMPERS! Always use the correct insulated adjustment tools.

6.1 Motor installation

- Foot-mounted motors must be level and secure.
- Ensure accurate alignment of the motor shaft and couplings.
- Do not hammer pulleys or couplings onto the motor shaft.
- Protect the motor from ingress of foreign matter during installation.

Earthing: Connect the motor to the system enclosure earth.

6.2 Drive Installation

Requirements during installation and operation:

HEATSINK AIRFLOW: Optimise the heatsink airflow.

- Avoid vibration.
- Protect the drive from pollutants.
- The ambient operating temperature must be within -10°C and +40°C.

POWER CABLING: Use correctly rated cable: minimum 600 Vac, 2 x armature current

FUSING: The drives have built-in line fuses for wiring protection:

400 6.3 A HRC 800 15 A HRC 1200 15 A HRC

Protect the drive thyristor bridge by fitting external semiconductor fuses. Refer to "7 Typical applications" on page 6. **CONTROL SIGNALS**: All control inputs to these drives are NON-ISOLATED. Do not connect any of the terminals to earth or other low voltage. A common HAZARD is accidental earthing of the external pot and contact wiring. Avoid running signal cables close to power cables.

SUPPRESSION: The drives have excellent noise immunity. However, installations involving electrical welding or RF induction heating may require additional filters on the line and armature terminals. Contactor coils and sparking contacts may also require suppression. A 100 Ω resistor in series with a 0.1 μ F capacitor is usually adequate in these situations. Refer to page 4 for EMC guidelines.



CAUTION! EQUIPMENT DAMAGE HAZARD

Reversing systems: do not transpose the armature connections until the motor has stopped, otherwise damage will occur.

SUPPLY: Please ensure that the supply selection jumper on the drive matches the incoming supply. Failure to do this may result in permanent damage to the drive unit and will invalidate any warranty.




CAUTION! EQUIPMENT DAMAGE HAZARD

For frequent stopping, it is not good practice to rely on switching the supply off and on again to stop and start the drive with the run contact permanently closed. This practice may result in an uncontrolled current pulse for one half mains cycle under certain conditions, e.g. main contact bounce, and might lead to undesired motor movement or device damage. In rapid start-stop systems, use

a spare normally-open contact on the main supply contactor in series with T5 and any other RUN contacts.

7 Typical applications







| | Drive model | Rating | Semiconductor fuse | A ² s |
|-------|-------------|--------|--------------------|------------------|
| | 400 | 8 A | CH006 08A | 35 |
| Fuses | 800 | 12 A | CH006 12A | 75 |
| | 1200 | 20 A | CH006 20A | 259 |

SPRINT ELECTRIC LTD. does not accept any liability whatsoever for the installation, fitness for purpose or application of its products. It is the users responsibility to ensure that the unit is correctly used and installed.

Health and Safety at Work

Devices constitute a safety hazard. It is the responsibility of the user to ensure compliance with any Acts or By-Laws in force. **ONLY skilled persons should install this equipment.**

8 Terminal descriptions

- 1 +10 V precision reference. 10 mA maximum. Short circuit proof
- 2 Minimum end of setpoint potentiometer or 4-20 mA current loop I/P
- **3** Speed demand input, 0-10 V for 0-100% speed
- 4 Common 4-20 mA return

Connect to COMMON to run 60 ms ON / 20 ms OFF (5 k Ω pull-up to +12 V)

- 5 WARNING: Run is an electronic inhibit function. The field remains energised and all power terminals remain "live". RUN must not be relied upon during hazardous operations
- 6 Tacho input 12-200 V full scale, + or polarity
- 7 Common
- 8 A+ armature output
- 9 A- armature output
- 10 F- field output
- 11 F+ field output
- 12 N Neutral AC supply input according to supply select jumper
- 13 L Line AC supply input according to supply select jumper
- **66** Auxiliary speed input, 0 to +10 V for 0-100% direct speed
- 65 Auxiliary inverting speed input, 0 to -10 V for 0-100% ramped speed
- 64 Torque input, 0 to +10 V for 0 to 100% current
- 63 -12 V output 10 mA maximum do not short

Stop/start input:

- 62 close to -12 V to activate stall condition close to +12 V to release stall condition
- 61 +12 V output, 10 mA maximum do not short

Speed output - typically 7.5 V full scale adjustment of maximum speed preset will alter
 the full scale reading from 4 V (anti-clockwise) to 9 V (clockwise)
 0 V to full scale represents 0 to 100% Impedance: 1 kΩ

55 Setpoint ramp output, 0-10 V, impedance $1 k\Omega$

54 Current output, 0-5 V for 0-100% of chosen range (S1, S2), 1 k Ω impedance

- 53 Zero speed relay driver output, maximum 100 mA, switches to -24 V
- 52 Stall relay driver output, maximum 100 mA, switches to -24 V
- **51** -24 V relay supply, 25 mA **do not short**



9 Block diagram




Figure 6 Block diagram



WARNING! PERSONAL INIURY HAZARD

This product is non-isolated, so ALL terminals and electronics are at dangerous line potential with power applied to the drive. Remember, all wires, potentiometers, contacts, etc., connected to the terminals will be floating at mains potential.

10 Commissioning

10.1 Initial settings - without power

The suggested Commissioning strategy starts in the safest possible mode of operation and progressively exercises each element of the system to achieve full functionality. For this reason, we ship all drive units to run using:

- the highest supply option
- at nominal speed
- ARMATURE VOLTAGE feedback mode
- 1. To avoid damage, ensure the supply selection jumper on the drive matches the incoming ac supply: 240 Vac or 110 Vac (60 Vac or 30 Vac for LV60 models).
- 2. Ensure switch S3 is set to OFF and S4 is set to ON to select AVF.
- **3.** Switches S1 and S2 select the range of the full-scale feedback voltage, e.g. if the armature voltage is 180 V, set S1 and S2 to ON; if 90 V, set S1 to OFF and S2 to ON.
- **4.** For an initial start, adjust the following presets for safety:

| DOWN RAMP | Fully anti-clockwise |
|-------------|---|
| UP RAMP | Fully anti-clockwise |
| MIN SPEED | Fully anti-clockwise |
| MAX SPEED | Fully anti-clockwise |
| STABILITY | Mid-way |
| IR COMP | Fully anti-clockwise |
| MAX CURRENT | Set the MAX CURRENT from your motor rating plate. Clockwise rotation of the potentiometer gives 0-100% of the drive current rating, e.g. 50% rotation provides 50% of the drive current rating. |

10.2 Pre-operation motor checklist

- 5. With no power applied, complete the following checklist:
 - All power and control connections are secure.
 - Check for the correct insulation between individual motor elements and between these elements and the earthed motor frame. Disconnect all drive cables before testing. The motor elements are: armature winding, temperature sensors*, tachogenerator* (* where applicable).
 - Check inside the motor connection box for foreign objects, damaged terminals, etc.
 - Check that motor brushes are in good condition, correctly seated and free to move in brush boxes.
 - Check for the correct action of brush springs.
 - Check that motor vents are free of any obstruction and remove any protective covers.



WARNING! PERSONAL INJURY HAZARD

This product is non-isolated, so ALL terminals and electronics are at dangerous line potential with power applied to the drive. Ensure that connected items (e.g. speed potentiometer, Tacho etc.) are NOT earthed and have sufficient dielectric strength to avoid breakdown.



WARNING!

When power is applied to the drive, ALWAYS use an insulated tool when adjusting the presets.




Figure 7 User adjustments



WARNING! PERSONAL INJURY HAZARD

RUN is an electronic inhibit function. The field remains energised, and all power terminals 'live'. During hazardous operations, remove the power source to the system. **RUN must not be relied on to ensure the machine is stationary.** The motor FIELD output remains energised with RUN open, so please beware of overheating the motor when stopped (does not apply to permanent magnet motors).

- 6. For this initial start, disconnect and insulate the (optional) Tacho connection to Terminal 6 as the drive will be using Armature Voltage feedback.
- 7. Note the Rated Armature Volts from the motor rating plate.
- 8. Apply power to the drive. The drive's ON lamp will light.
- 9. Operate the RUN switch to turn the motor.
- Slowly increase the external speed potentiometer to start the motor rotating. The motor will ramp up slowly to a nominal or base speed. DO NOT exceed the motor's rated voltage.
- **11. Is the motor turning in the required direction?** If not, reverse the system by transposing the A+ and A- motor armature connections.



CAUTION!

When reversing the system: To prevent damage, do not transpose the ______ motor armature connections until the motor has stopped rotating.

- 12. MAX SPEED: Increase the external setpoint further to ramp up to full speed. Fine adjust using the MAX SPEED preset to achieve the armature voltage stated on the motor rating plate.
- **13.** Reduce the external setpoint to ramp the drive to zero. The motor will stop rotating.
- **14. MIN SPEED**: Adjust the **MIN SPEED** preset to provide a speed preset (for use where an external setpoint is not in use).
- **15. RAMP UP/RAMP DOWN**: Run the motor speed up and down while adjusting the **RAMP UP** and **RAMP DOWN** presets.
- **16. STABILITY**: Adjust the **STAB** preset to improve response. Clockwise rotation gives a faster response (excessive rotation in either direction may lead to instability, depending on load).
- **17. IR COMP**: Speed droop may occur where ARMATURE VOLTAGE feedback mode is used (default). Compensate for this by rotating the IR COMP preset clockwise (excessive rotation may lead to instability).

The drive is now fully commissioned in ARMATURE VOLTAGE feedback mode.

NOTE: DO NOT use IR compensation with Tachogenerator feedback - set the IR COMP preset fully anti-clockwise.

- 1. For systems using Tach Feedback, first, measure the full speed tacho voltage while in AVF mode and determine the polarity the wire to T9 must be negative when the speed demand into T3 is positive:
 - 1. Having measured the Tach voltage at maximum speed, TURN OFF THE POWER.
 - 2. Set switch S4 to OFF to select TACHO operation.
 - 3. Set switches S1 and S2 to select a speed range encompassing the tacho voltage measured under AVF operation. For example, if the tachogenerator is 60 V/1000 rpm and the motor speed is 1500 rpm, then the tacho voltage is 90 V, and this is within the voltage range 50-100 V provided by setting S1 to OFF and S2 to ON.
 - 4. Adjust the MAX SPEED preset to approximately match the full-scale Tach output or mid-position. For example, for a 90 V tacho input using the 50-100 V range, the preset's position would be 80% rotation.
 - 5. Re-connect T9, **TURN ON THE POWER**, run the drive, and finely adjust MAX SPEED. Increase the MAX CURRENT preset to correspond to the motor armature current.
- 2. **STABILITY**: Adjust the **STAB** preset to improve response. Clockwise rotation gives a faster response (excessive rotation in either direction may lead to instability, depending on load).

The drive is now fully commissioned in TACHO feedback mode.

11 Options

Consider the following changes to tune/improve the performance of the drive/system.

TORQUE CONTROL MODE: When ON, switch S3 allows a Torque signal to enter via signal pad 64 (TI). The pad is on the top edge of the board.

TORQUE (0-10 V input on T64):


Refer to "7 Typical applications" on page 6 and "Figure 6 Block diagram" on page 8.

ON for Torque Control mode OFF (normally off).

In Torque Control mode, the lowest setpoint has priority. Hence, the speed setpoint sets a demand for speed slightly in excess of the system's working speed, meaning the torque setpoint always operates as the limit. For example, in the event of a web break, the motor will only run-up to the level set on the speed potentiometer.

12 Trouble shooting

The drive consists of two highly accurate feedback control loops.





WARNING! PERSONAL INIURY AND/OR EQUIPMENT DAMAGE HAZARD This drive is NON-ISOLATED:


Do not connect the electronics to earth or other non-isolated voltage. Connecting to other instruments, e.g. a panel meter: ensure the instrument can float safely at high voltage.

Remember, all wires, potentiometers, contacts, etc., connected to the terminals will be floating at mains potential.

- 1 STALL problems, indicated by the STALL lamp coming on after running, are caused by the drive unit being unable to give the set speed.
- 2 Typical STALL reasons:
 - MAX CURRENT preset not correctly a. set, hence insufficient torque.
 - b. Motor not powerful enough for the application. Speed calibration is set beyond the capability of supply.
 - Any factor which prevents the с. motor from rotating at set speed, e.g. jammed load; low supply voltage.
- 3 Pot wiring T2 and T1 transposed. Motor slows down instead of speeding up.
- Pot wiring T2 and T3 transposed. Motor 4 slows down for clockwise rotation. T1 may be shorted to T2.
- 5 Pot wiring T1 and T3 transposed. Motor slows down for anti-clockwise rotation. T1 becomes shorted to T2.
- Any pot wire or internal electrical part of 6 pot earthed. This causes critical damage. Check before power-on.

- Loose or intermittent tacho coupling 7 causes instability or overspeeding. Make sure coupling is secure and non-elastic.
- 8 Incorrect feedback scaling causes overspeeding. Calculate the desired maximum tacho volts - adjust S1, S2.
- **9** Tacho failure. Until a replacement is fitted, change to ARMATURE VOLTAGE feedback, S4. Rescale with S1, S2.
- **10** Armature resistance should usually be a few ohms. The armature time constant must be greater than 10 milliseconds.
- **11** Shorted turn on motor armature can cause power device failure. Check resistance through 360° rotation.
- 12 Brushes should be in good condition, correctly seated, and free to move in brush boxes.
- **13** Field resistance should usually be a few hundred Ohms. Isolate the field from the earth and the armature.
- **14** Do not open-circuit the field. Do not open-circuit the armature unless opening RUN first.
- **15** The AC supply must lie within the limits specified on page 15. Ensure the selection jumper is correct.

Trouble shooting





13 Specifications

| Function | Specification | | | | Comments | |
|---|--|------------------------------|-------------------------|-------------|--|---|
| CONTROL ACTION | DUAL LO | OP PROPO | RTIONAL + | | | |
| FEEDBACK METHOD | ARMATURE VOLTS TACHOMETER | | | | | SWITCH SELECTABLE |
| 0-100% REGULATION | 2% TY | 2% TYPICAL 0.1% TYPICAL | | | | |
| MAX TORQUE SPEED RANGE | 20 | 20:1 100:1 | | | | BEWARE MOTOR HEAT AT LOW |
| OVERLOAD | 150% CO | NTINUOUS | CURRENT | FOR 30 SEC | CONDS | SPEED |
| Customer Presets | | | | | | |
| MAX SPEED | 12 - 200 \ | FULL SCA | LE FEEDBA | ΞK | | SWITCH SELECTABLE |
| MIN SPEED | 0-50% OF | MAX SPEE | D | | | NON-INTERACTIVE |
| UP/DOWN RAMPS | INDEPEN | DENTLY AD | JUSTABLE | -30 SECON | IDS | LINEAR RAMPS |
| STABILITY | VARIES SF | PEED LOOP | GAIN | | | |
| IR COMPENSATION | 0-30% OF | ARMATUR | E VOLTAGE | | | DO NOT USE WITH TACHO |
| MAX CURRENT | LINEAR S | ETTING FRO | OM 0-100% | 1 | | 150% OVERLOAD |
| Switch Selectable | | | | | | |
| SPEED RANGE | FOUR RAI | NGES OF FE | EDBACK V | OLTAGE | | S1, S2 |
| TORQUE MODE | | | -100% CUR PEED PROTI | | ł | 53 |
| TACHO/AVF | SELECT TA | ACHO OR A | RMATURE | S4 | | |
| Jumper Functions | | | | | | |
| SUPPLY SELECT | DUAL SUF | DUAL SUPPLY VOLTAGE SELECTOR | | | JUMPER SELECTABLE | |
| Link Functions | | | | | | |
| 4-20 mA OR 0-20 mA LOOP | ALLOWS | CURRENT L | OOP SIGN | AL INPUT F | OR SPEED | 5 V COMPLIANCE |
| 50% STALL LEVEL (STH LINK) | ALLOWS I | ARGE PEA | K CURRENT | S | | 150% PEAK |
| SUPPLY RANGES | | LV30 | LV60 | 110 | 240 | |
| 45 Hz to 65 Hz | MAX | 36 V | 72 V | 130 V | 264 V | OVER THE FULL TEMP RANGE WITH OUTPUTS LOADED |
| AUTO RANGING | MIN | 27 V | 54 V | 100 V | 200 V | |
| SIGNAL OUTPUTS | SPEED, Cl | JRRENT, RA | AMP | | | ALL BUFFERED |
| RELAY OUTPUTS | STALL, ZE | RO SPEED | RELAY DRIV | FOR -24 VDC | | |
| RAIL OUTPUTS | -24 V UNF | -24 V UNREGULATED 25 mA | | | | +/- 20% |
| | +12 V, +10 V, -12 V REGULATED 10 mA | | | | 0.01%/°C 5% | |
| FIELD OUTPUT | 0.9 (0.45) x AC SUPPLY. 0.5 A MAXIMUM | | | | FULL (0.9) OR HALF WAVE (0.45) | |
| IP RATING | IPOO | | | | | |
| ALTITUDE | 3000 METRES MAXIMUM FOR FULL RATING | | | | DE-RATE 1%/100 m | |
| HUMIDITY | 85% R.H. AT 40°C, NON-CONDENSING | | | | | |
| FORM FACTOR | TYPICAL 1.5 AT MAXIMUM OUTPUT | | | | | |
| TEMPERATURE | STORAGE AND OPERATING -10 TO +50°C AMBIENT | | | | | |
| MAX I ² t FOR EXTERNAL FUSING (Amps ² Seconds) | MODELS | 400/800 = | 50 I²t. MOE | 365 I²t | SEMICONDUCTOR FUSES - REFER TO SUPPLIER | |

©2021, Sprint Electric. All rights reserved.

We accept no liability whatsoever for the installation, fitness for purpose or application of this product.

It is the user's responsibility to ensure the unit is correctly used and installed.

This leaflet is protected by copyright. No part of it may be stored or reproduced in any form without written permission from Sprint Electric.

The information in this publication was correct at the time of going to print.

We reserve the right to modify or improve the product without notification.

The contents of this manual shall not become part of or modify any prior existing agreement, commitment, or relationship. The sales contract contains the entire obligation of Sprint Electric. The warranty contained in the contract between the parties is the sole warranty of Sprint Electric. Any statements contained herein do not create new warranties or modify the existing warranty.

We will be under no liability for any defect arising from fair wear and tear, negligence, wilful damage, misuse, abnormal working conditions, failure to follow the manufacturer's instructions, unauthorised alteration or repair of hardware, unauthorised or accidental alteration of software or configuration, lost profits, commercial loss, economic loss, or loss arising from personal injury. We may, at our discretion, raise a charge for any faults repaired that fall outside the warranty cover.

Sprint Electric Limited, Peregrine House, Ford Lane, Ford, Arundel <u>BN18 0DF</u>, U.K. Tel: +44 (0)1243 558080 Fax:+44 (0)1243 558099 Email: <u>info@sprint-electric.com</u>